




Danfoss Link RS

Danfoss Link RS Room Sensor is an electronic sensor for measuring room temperature.

The Room Sensor is a part of the Danfoss Link system, which is used for wireless linking and controlling of heating systems in residential and light commercial buildings.

The Danfoss Link RS Room Sensor has a built-in temperature sensor, which measures the ambient temperature. It allows you to control the heating, based on room temperature in the room where installed. With the Danfoss Link RS you can also adjust the requested temperature.

Technical specifications

Benefits <ul style="list-style-type: none"> • Heating regulation • Wireless connected to Danfoss Link CC • Actually temperature view • Adjustable • Daily overview • Weekly schedule • Minimize energy consumption Approvals:  Standard compliance <ul style="list-style-type: none"> • EN 60730 • EN 300 220-25 	Battery	2 x 1,5 V AA alkaline
	Battery life	Up to 4-5 years
	Backlight	White LED
	Battery level	Indication in display
	Ambient temperature	0° to +40° C
	Transmission frequency	868,42 MHz
	Transmission range in normal buildings	Up to 30 m
	Transmission power	Max. 1 mW
	IP class	21
	ErP class	4
	Dimensions	76 mm x 76 mm x 23 mm

Types

Item no.	Product name	Type	EAN no.
088L1914	Danfoss Link RS	Room sensor - Wireless - Battery Supply	5703466224427

Danfoss Link system units

Item no.	Product name	Type	EAN no.
014G0286	Danfoss Link CC	Danfoss Link™ Central Controller - Wi-Fi	5702425112874
088L1905	Danfoss Link FT	Floor Thermostat with ELKO frame	5703466174371
088U0230	Danfoss Link RU	Repeater Unit	5702420068244

Accessories

Item no.	Product name	Type	EAN no.
014G0262	Danfoss Link Battery supply unit (BSU)	Battery Supply Unit	5702420110653

Do not install floor heating systems without a floor sensor when the heating element is installed on or beneath wooden surfaces and other surfaces sensitive to temperature!